

DSC Quick & Easy

1. To Arm System, (green check-ready light must be on).
Press **STAY** button (2-3 seconds) - Will arm system with _____ bypassed.
Press **AWAY** button (2-3 seconds) - Will arm system with all zones on.
To arm system with No Delay in Stay Mode enter *, 9, User Code.
2. To Disarm system, enter User Code.
3. The same User Code cuts off the siren.
4. Enter & Exit through Delay door (when arming & disarming).
With STAY or AWAY arming you have entry & exit delay time.
5. Press **CHIME** button (2-3 seconds) - turns door/window chime On or Off (toggles).
6. Smoke Detector, Fire Alarm, to silence, enter User Code.
Press **RESET** button (2-3 seconds) - To reset smoke detectors (when clear of smoke).
7. Press **EXIT** button (2-3 seconds) - Quick Exit, if system is already armed, it will give you up to 2 minutes to exit through one delay door without changing arming status, can only open door one time.
8. Panic Buttons, Press **FIRE, MEDICAL, PANIC** (2-3 seconds) to Activate a Emergency Alarm.
9. To change the (master) User Code, enter *, 5, current master user code (default 1234), 40, new 4 digit master user code, # to exit.
10. To reset the clock, enter *, 6, (master) User Code, 1, enter time (in military time), then date, #, to exit. format: HH:MM, MM/DD/YY.
Example, if code is 1234, time is 4:15pm and date is 04/15/10 you enter these keys:

* 6 1234 1 1615 041510 #

Arming = Turning alarm on

Disarming = Turning alarm off

Enter or Press a key = Same thing

Panic & Function Keys must be pressed in for approx. 3 seconds to work, Panic on a Keyfob approx. 5 seconds